



## THREE POSITION CROWN

- 1 Normal Position (for winding)
- For date correction, turn clockwise
   For day correction, turn counter clockwise
  [setting wanted language,
  indicator bilingual]
- 3 For setting the hands (stopping second)